



MOUNTAIN RESCUE TRAINING MANIKIN

FOR PROFESSIONALS WHO SAVE LIVES

Developed with Scottish Mountain Rescue, this manikin solves a key challenge: standard models are too heavy for realistic mountain training. Lightweight and rugged, it's purpose-built for remote rescue scenarios.

Weighing just 11 kg, it folds into an integrated backpack for easy transport. A foam-filled body provides realistic resistance for avalanche probing, while flame-retardant fabric ensures durability in extreme terrain. The only avalanche manikin with RECCO® reflectors, it's searchable by teams using this globally trusted system.

Light to carry, tough in the field, and ready for rescue.



PART OF PROTECT MEDICAL.
GET IN TOUCH TO FIND OUT
MORE ABOUT THE RANGE
OF MEDICAL AND RESCUE
PRODUCTS AVAILABLE FROM
OUR SISTER BRANDS.

SPEAK TO THE EXPERTS:

📞 +44 (0) 1490 413 282 ✉️ MAIL@RUTHLEE.CO.UK 💻 WWW.RUTHLEE.COM



MOUNTAIN RESCUE TRAINING MANIKIN

IDEAL FOR THE FOLLOWING TRAINING SCENARIOS:

Specially designed to be transported to locations which are difficult to access, and also suitable for use by mountain search and rescue professionals. RECCO® reflectors built in to the manikin are searchable by transceivers commonly used by avalanche rescue teams in over 800 ski resorts worldwide. (See www.recco.com for more information).

SPECIAL MATERIALS:

Constructed from the same flame retardant material used in Police ballistic/stab vests, offering 4x the strength and abrasion resistance of 16oz canvas or P.V.C. (conforms to OEKO-TEX® Standard 100, BS EN ISO 12947-2 & 14116: 2008). High density webbing (25mm rated to 200 Kg, 50mm rated to 435Kg with a +/-5% range). RECCO® reflectors.

FEATURES & BENEFITS:

- Light weight at only 11Kg for ease of transportation in the backpack supplied with the manikin.
- Filled with foam to give the bulk and firmness of a body, and demonstrating a 'spongy resistance' when probing, for added realism.

AVAILABLE WEIGHTS & SIZES:

DESCRIPTION	MODEL CODE	HEIGHT (M)	WEIGHT (KG)	NATO STOCK #
Adult	RLNAV	1.8	11	N/A

- Secure pockets to protect an electronic transceiver if used.
- Life-like facial features with mouth cavity to check for obstructions.
- Water repellent and non absorbent, material to reduce drying time after exercises.
- Soft body joints to eliminate the risk of pinch welts and bruising; common injuries when using plastic bodied manikins.
- An immobilisation/extrication collar can be fitted around the neck of our adult manikins to promote proper casualty care.
- Comes complete with boots, overalls and backpack, which are easily replaced if damaged.

NOT SUITED FOR:

- Use in temperatures above 100°C or flashover scenarios – See our Fire House manikin.
- Use in water – See our Water Rescue range.

EXTENSIVELY USED BY:

- Mountain rescue teams in the UK.
- Avalanche rescue teams in alpine regions.
- Equivalent organisations across North & South America, Europe, Australia and Asia.