



CASUALTY EVACUATION TRAINING MANIKIN

FOR PROFESSIONALS WHO SAVE LIVES

The Casualty Evacuation Training Manikin is purpose-designed to meet the exacting standards of firefighter recruitment and annual fitness testing, as outlined by the Chief Fire Officers Association. Built to replicate the realistic weight and feel of an unconscious casualty, it ensures candidates are tested under conditions that reflect the demands of real-life rescues.

This manikin is also the perfect choice for the Drag Test element of firefighter challenges and competitions. Its robust construction withstands repeated use on a variety of surfaces, making it a reliable and long-lasting training partner for high-intensity scenarios.

**PROTECT
MEDICAL**

PART OF PROTECT MEDICAL.
GET IN TOUCH TO FIND OUT
MORE ABOUT THE RANGE
OF MEDICAL AND RESCUE
PRODUCTS AVAILABLE FROM
OUR SISTER BRANDS.

SPEAK TO THE EXPERTS:

☎ +44 (0) 1490 413 282 ✉ MAIL@RUTHLEE.CO.UK 💻 WWW.RUTHLEE.COM



CASUALTY EVACUATION TRAINING MANIKIN

IDEAL FOR THE FOLLOWING TRAINING SCENARIOS:

The Casualty Evacuation training manikin was specifically designed for the Fire Fighter recruitment and annual fitness test as specified by the Chief Fire Officers Association.

It would also be the ideal choice for the Drag Test element of Fire Fighter challenges and competitions, being robust and hard-wearing.

SPECIAL MATERIALS:

Constructed from the same flame retardant material used in Police ballistic/stab vests, offering 4x the strength and abrasion resistance of 16oz canvas or P.V.C. (conforms to OEKO-TEX® Standard 100, BS EN ISO 12947-2 & 14116: 2008). High density webbing (25mm rated to 200 Kg, 50mm rated to 435Kg with a +/-5% range).

FEATURES & BENEFITS:

- Anatomically correct weight distribution to give the 'feel' of an unconscious casualty.
- Supplied complete with leg protectors making it perfect for drag tests. Replacement plastic strips for the leg protectors can be bought separately as required.

- Strong webbing loop at the back allows easy handling, storage and suspension for drying.
- Tough enough to withstand being dropped from a house rooftop.
- Soft body joints to eliminate the risk of pinch welts and bruising; common injuries when using plastic bodied manikins.
- Water repellent material, making it suitable for wet or foul conditions.
- Comes complete with boots which are easily replaced if damaged.

NOT SUITED FOR:

- Use in temperatures above 100°C or flashover scenarios – See our Fire House manikin.
- Use in water – See our Water Rescue range.

OPTIONAL EXTRAS:

- Additional Leg Protectors can be purchased as and when required to prolong the life of your manikin.

EXTENSIVELY USED BY:

- UK Fire Service.
- Equivalent organisations across North & South America, Europe, Australia and Asia.

AVAILABLE WEIGHTS & SIZES:

DESCRIPTION	MODEL CODE	HEIGHT (M)	WEIGHT (KG)	NATO STOCK #
Adult	RLNCE	1.8	55	N/A
Adult	RLNCE110	1.8	110	6910-99-309-2595

*Manikins weighing over 50kg may have metal ballast as part of their construction. Please contact us for more information.