

RUTH LEE™



# MOUNTAIN RESCUE TRAINING MANIKIN

## FOR PROFESSIONALS WHO SAVE LIVES

Ruth Lee is a family business whose core values revolve around the care of our employees, service to our customers and uncompromising product quality. We are proud to serve YOU, the dedicated professionals who make such a valuable contribution to society.

We employ highly skilled people and source the most durable materials to ensure our products meet the highest international standards.

Our manikins are designed to represent the correct anatomic weight distribution of a real person, and we offer a range of different models to suit every conceivable scenario. This ensures that your training is as realistic and as effective as possible; preparing you for all eventualities.

LEARN MORE ABOUT OUR EXTENSIVE RANGE OF TRAINING MANIKINS, BESPOKE BAGS, OPERATIONAL PRODUCTS AND FIRE SIMULATION EQUIPMENT

CALL OUR EXPERTS:

+44 (0) 1490 413 282

SALES@RUTHLEE.CO.UK

WWW.RUTHLEE.CO.UK



# MOUNTAIN RESCUE TRAINING MANIKIN

## IDEAL FOR THE FOLLOWING TRAINING SCENARIOS:

Specially designed to be transported to locations which are difficult to access, and also suitable for use by mountain search and rescue professionals. RECCO® reflectors built in to the manikin are searchable by transceivers commonly used by avalanche rescue teams in over 800 ski resorts worldwide. (See [www.recco.com](http://www.recco.com) for more information).

## SPECIAL MATERIALS:

Constructed from the same flame retardant material used in Police ballistic/stab vests, offering 4x the strength and abrasion resistance of 16oz canvas or P.V.C. (conforms to OEKO-TEX® Standard 100, BS EN ISO 12947-2 & 14116: 2008). High density polypropylene webbing (25mm rated to 207 Kg, 50mm rated to 440Kg). RECCO® reflectors.

## FEATURES & BENEFITS:

- Light weight at only 11Kg for ease of transportation in the backpack supplied with the manikin.
- Filled with foam to give the bulk and firmness of a body, and demonstrating a 'spongy resistance' when probing, for added realism.

- Secure pockets to protect an electronic transceiver if used.
- Life-like facial features with mouth cavity to check for obstructions.
- Water repellent and non absorbent, material to reduce drying time after exercises.
- Soft body joints to eliminate the risk of pinch welts and bruising; common injuries when using plastic bodied manikins.
- An immobilisation/extrication collar can be fitted around the neck of our adult manikins to promote proper casualty care.
- Comes complete with boots, overalls and backpack, which are easily replaced if damaged.

## NOT SUITED FOR:

- Use in temperatures above 100°C or flashover scenarios – See our Fire House manikin.
- Use in water – See our Water Rescue range.

## EXTENSIVELY USED BY:

- Mountain rescue teams in the UK.
- Avalanche rescue teams in alpine regions.
- Equivalent organisations across North & South America, Europe, Australia and Asia.

## AVAILABLE WEIGHTS & SIZES:

DESCRIPTION	MODEL CODE	HEIGHT (M)	WEIGHT (KG)	NATO STOCK #
Adult	RLNAV	1.8	11	N/A